



GEOLOGICAL SURVEY OF INDIA

INTRODUCTION TO HYPERSPECTRAL REMOTE SENSING

(Hyperspectral & Spectroscopy)

Geological Survey of India
Training Institute
Mission-V



e-GSITI ज्ञान प्रसारण के माध्यम से उत्कृष्टता की ओर
xcellence through knowledge sharing
24x7

Follow us on:     

www.gsi.gov.in



Introduction to Hyperspectral Remote Sensing (Hyperspectral & Spectroscopy)



Dr. Nisha Rani

Superintending Geologist,
PGRS Division, GSITI, Hyderabad

Email: nishargsi@gmail.com

nisha.rani@gsi.gov.in

- ❖ Hyperspectral Remote Sensing
- ❖ Multispectral to hyperspectral
- ❖ Concepts of spectroscopy
- ❖ Spectroradiometer
- ❖ Hyperspectral sensors
- ❖ Hyperspectral data processing


Follow us on:










Hyperspectral Remote Sensing

- Hyperspectral sensors acquire image in many narrow contiguous spectral bands throughout the visible, near infrared (VNIR) and shortwave infrared (SWIR) from 0.4 to 2.5 μm wavelength range simultaneously at 5-10 nm band width.
- Hyperspectral remote sensing combines imaging and spectroscopy in a single system, which often includes large data sets and require new processing methods.




Follow us on:





Multispectral Vs Hyperspectral



Follow us on:






Multispectral Vs. Hyperspectral

Broadband



Multispectral



Hyperspectral



	Multispectral	Hyperspectral
No. of Bands	<100	>100
Wavelength	Discrete	0.4-2.5 μm
Spectral Width	80-100 nm	5-10 nm
Spatial Resolution	30m	30m and 5-8 m for AVIRIS-NG

Follow us on:







❖ *Hyperspectral imageries are typically collected in 3-D with spatial information in X-Y plane and spectral information in the Z plane.*

❖ *Advantage with the hyperspectral data is that it facilitate image analysis as well as spectroscopic study in the form of spectral signature for each pixel*

❖ These spectral signatures discriminate individual minerals based on their absorption features.



Follow us on:





- Can be used to delineate a variety of minerals that broadband, low resolution systems such as Landsat are unable to demarcate.
- Hydrothermal alteration is commonly indicated by iron oxide, hydroxyl bearing minerals, carbonates and sulfate, which produce characteristic signatures throughout the VNIR and SWIR range as an outcome of electronic and vibrational processes .
- Spectral range from 0.4 to 1.0 μm (VNIR) range is important for mapping iron oxides (hematite, goethite, limonite, jarosite).
- Spectral range from 2.0 to 2.5 μm is useful for mapping of hydroxyl-bearing minerals, sulfates and carbonates, common to many geologic units and hydrothermal alteration assemblages



Follow us on:





Application of Hyperspectral Remote Sensing



Follow us on:





Spectroscopy Of Major Minerals And Spectral Resolution Requirement(cloutis,1996)

Mineral Group	Characteristic absorption depth of absorption signature	Spectral Resolution Required
Olivine	near 1 μm ,0.65 μm	30 nm is required in the 1 μm wavelength region to permit the lowest level of quantitative compositional information
Pyroxene	near 1 μm and 2 μm	130 nm to 500 nm
Amphibole	absorption features near 1.1 μm , 1.4 μm , and 2.3-2.4 μm	Approximately 60 nm
Feldspar	1.1-1.3 μm	At least 200 nm can be used to constrain major (Ca, Na) and minor (Fe) element abundances and grain sizes
Clay	1.4,1.9,2.2 μm	15-20 nm is required to differentiate clay mineral. Spectral resolution on the order of 50-100nm is only useful for identifying the presence or absence of clay minerals.
Carbonate	2.3 to 2.4 μm	Approximately 10 nm
Iron Oxides/Hydroxides	0.4 μm , 0.7 μm	Differences in band positions between different species may be as small as 10nm.

Follow us on





Useful wavelength range for Mineral Exploration

Visible – Near Infrared (VNIR-0.35 to 1 μm)

- ❖ Iron Oxides (Fe^{2+} , Fe^{3+})
- ❖ Rare Earth Element Oxides

Short Wave Infrared (SWIR- 1 to 2.5 μm)

- ❖ Carbonates (CO_3 - Calc, Magn, Dolo, Fe carb)
- ❖ Phyllosilicates
- ❖ Sulfates (Alunite, Jarosite)
- ❖ Al – OH & Fe – OH (-Clay, Muscovite, Chlorite)
- ❖ Mg – OH (Serpentines, Chlorites, Biotite, Phlogopite, Amphiboles)

Long Wave Infrared (Thermal or TIR > 2.5 μm)



- ❖ Silicates (Qtz, Fsp, Gt, Px, Ol, Am, Clays, Micas)
- ❖ Sulfates (Alunite, Jarosite, Gypsum, Anhydrite)
- ❖ Carbonates (CO_3 -Calcite, Magnesite, Dolomite)
- ❖ Phosphates (Apatite)

Follow us on:





❖ Lithological Mapping




Follow us on:





❖ Lithological Mapping




Follow us on:





Hydrothermal alteration Zone Mapping/ Mineral Mapping



Alteration Zones

Mineral Assemblages

Propylitic Zone

Epidote, Calcite, Chlorite

Argillic Zone

Quartz, kaolinite, montmorillonite

Ad. Argillic Zone

Kaolinite, dickite, pyrophyllite

Phyllic zone

Quartz, sericite, pyrite, muscovite

Potassic zone

Biotite, k-feldspar, quartz, sericite,


CLASSICAL ALTERATION MODELS SHOWING HYDROTHERMAL ALTERATION ZONES (Lowell and Guilbert, 1970)

Follow us on:






Over the last two decades, like **AVIRIS**, **HYDICE**, **DAIS**, **HyMAP** have been extensively attempted. *mineral mapping and lithological discrimination using airborne hyperspectral sensors*



Mapping results from the analysis of visible to near infrared (VNIR) **AVIRIS** airborne hyperspectral imagery over **Cuprite, Nevada** (from Clark et al., 2003).




Mapping results from the analysis of short-wave infrared (SWIR) **AVIRIS** airborne hyperspectral imagery over **Cuprite, Nevada** (from Clark et al. 2003).

Follow us on:





Follow us on:



- The EO-1 Hyperion sensor was launched in November 2000.
- Hyperion have 242 spectral bands covering VNIR to SWIR region with 7.65 km swath and 185 km long (along-track) region.
- The image consists of 30 m x 30 m pixels, in which the spectrum for each portion is provided

Mapping results from the analysis of Hyperion ((VNIR-SWIR) spaceborne imagery over Gadag Schist belt

Source: Rani N. 2016





Jahazpur



Magnesium carbonate-bearing host rocks appear in shades of maroon to purple, talc-bearing pixels appear in yellow, kaolinite in blue and montmorillonite in green.

Ambaji



FCC, combined olivine- and carbonate-bearing pixels appear in yellow, magnesium carbonate in red to orange to maroon, soap stones (talc) in magenta, kaolinite in bluish-green and montmorillonite in dark green.


Follow us on:

Source: Bhattacharya et al., 2019





Jahazpur



Source: Jain and Sharma, 2018

Figure 4: Mineral distribution maps of the different minerals after applying the threshold values on the fit images generated by SFF algorithm. A: Clay minerals, B: Dolomite, C: Iron minerals (pyrrhotite & limonite), D: Other minerals (Talc, quartz & vermiculite).

Follow us on:





Geo-botany

- ❖ Geo-botany has been defined as the study of plants as related specifically to their geologic environment which includes :
- ❖ Spatial distribution of plants and plant communities as related to geology.
- ❖ Vegetation characteristics (physiology, morphology, anatomy, biochemistry) as related to geology.
- ❖ Reflectance spectra of foliage growing over mineralized areas may differ from spectra of foliage in adjacent non-mineralized areas.
- ❖ Vegetation is often influenced by mineralization, lithology, and rock fracturing.




Follow us on:







- Sites with high concentration of old mine tailings for lead, copper, zinc, nickel and other metals may develop unique floras because condition is toxic for most species.
- **Naturally occurring saline or alkaline deposits and serpentine outcrops also develop unique floras.**
- Leaf concentration of trace metals may indicate the composition of underlying soil and thus may be useful for mineral exploration.




Follow us on:





Spectroscopic Study



Follow us on:





Other Applications of Hyperspectral data

- ❖ **Atmosphere:** water vapor, cloud properties, aerosols.
- ❖ **Ecology:** chlorophyll, leaf water, cellulose, pigments, lignin.
- ❖ **Geology:** mineral and soil types.
- ❖ **Coastal Waters:** chlorophyll, phytoplankton, dissolved organic materials, suspended sediments.
- ❖ **Snow / Ice:** snow cover fraction, grain size, melting.
- ❖ **Biomass Burning:** sub-pixel temperatures, smoke.
- ❖ **Commercial:** mineral exploration, agriculture and forest production.




Follow us on:





SPECTROSCOPY

- ❖ Contiguous bands of Hyperspectral data allows spectroscopy or spectrometry study of surface material.
- ❖ The spectroscopy is the study of light as a function of wavelength that has been emitted, reflected or scattered from solid, liquid or gas.
- ❖ The Hyperspectral imagery / Spectroscopy can detect individual absorption features, specific chemical bonds in solid or liquid
- ❖ Which allows identification of mineral or chemical composition of material or mineral.
- ❖ These spectral signatures discriminate individual minerals based on their absorption features.



Follow us on:





Spectroscopy / Reflectance Remote Sensing

There are two processes responsible for the absorption of light at certain wavelength:

1. Electronic Process,
2. Vibrational Process

Electronic:

- Mainly occurring in the VNIR (0.3 to 1.0 μm) region.
- When light interacts with any material or mineral, at specific wavelength photon will be absorbed, which causes change in energy from low to higher one.
- Most common electronic process revealed in the spectra of minerals is due to unfilled electron shells of transition elements (Fe, Mn, Ni, Cr, Co etc).
- The absorption bands can also be caused by charge transfers or inter-elemental charge transition where the absorption of photon causes an electron to move between ions or ions and ligands.
- The transition can also occur between the same metal in different valence states, such as Fe^{2+} and Fe^{3+} .

Follow us on:





Electronic Processes

- **Crystal field:** absorption due to unfilled electron shells, transition metals are promoted to higher shells, depends on crystal structure.
- **Charge transfer:** electron move between ions $\rightarrow \text{Fe}^{2+} \rightarrow \text{Fe}^{3+}$.
- **Conduction bands:** two discrete energy levels for electrons, conduction band and valence band.
- **Color centres:** irradiation in UV of a imperfect crystal)
- High energy –High wavelength features

Follow us on:





Vibrational Absorption

- ❑ The vibrational process is dominated in the SWIR (1 to 2.5 μm) region of the electromagnetic spectrum.
- ❑ The bonds in a molecule or crystal lattice are like springs with some attached weights: the whole system can vibrate.
- ❑ The frequency of vibration depends on the strength of each spring and their attached masses.
- ❑ It is called combination tones when they involve different modes of vibrations (Clark, 1999).
- ❑ The SWIR (1.0- 2.5 μm) is useful for mapping hydroxyl bearing minerals including clay and sulfate, carbonate minerals.



Follow us on:






Vibrational Processes

- The bonds in molecule or crystal lattice are like springs with attached weights: the whole system can vibrate
- Low energy-high wavelength features


symmetric stretching




asymmetric stretching




bending





Stretching



Asymmetric Stretching



Bending



Follow us on:






Processing Techniques

For Multispectral

- FCC
- Band Ratio
- PCA
- Classification

For Hyperspectral Data




Software: ERDAS, ENVI, Arc-GIS


Software: ENVI

Follow us on:






Hematite




Kaosmec

Source: Rani N. 2016



Kaolinite




Kaolinite


Follow us on:



Source: Rani N. 2016



Muscovite



Grey soil

Follow us on:



Source: Rani N. 2016



Spectroscopic Study and Collection of Spectra

- ❖ With the advent of compact and sophisticated spectrometers and spectroradiometers, field spectroscopy is evolving as a robust technique in mineral exploration.
- ❖ Spectral absorption features of minerals (such as silicates, oxides, hydroxides, carbonates, sulphides, nitrates and borates) are well established and identification of these minerals based on spectra is now possible.

ASD (Analytical Spectral Device) Spectroradiometer:

- The Spectroradiometer records the spectral reflectance within the wavelength range of 350 nm to 2500 nm and it has a spectral resolution of 3 nm.

Follow us on:






ASD Spectroradiometer, Laboratory



ASD Spectroradiometer, Field


Follow us on:





Spectral Signature through Spectroradiometer in the Laboratory condition


Source: Rani, 2016



Spectral Signature of rocks generated through Spectroradiometer in the Field condition

Follow us on:





Continuum removed spectra of the samples (red) matched with corresponding USGS and JHU (black) reference spectra for the identification of the former. (A) sample 1 versus clinocllore; (B) sample 2 versus margarite; (C) sample 3 versus anorthite; (D) sample 4 versus greyish brown loam; (E) sample 5 versus montmorillonite; (F) sample 6 versus chlorite; (G) sample 7 versus kaolinite; (H) sample 8 versus hematite

Follow us on:





What is spectral library?

- The spectral library is a collection of spectra of natural and man made materials.
- These libraries provide a source of reference spectra of varieties of targets (minerals, rocks, vegetation species) for remote identification for these targets.

Some important laboratories for spectral signatures

[JHU\(John Hopkins University\) Laboratory](#)

- Minerals(2-25 micrometer)
- Rocks(0.4- 15 micrometer)
- Manmade features(0.3- 12.5 micrometer)
- Lunar rock samples

[USGS laboratory](#)

- Minerals
- Vegetation (Visible-near infrared – shortwave domain)

[JPL](#)

Follow us on:





Thank You

Follow us on:

